



ATMEGA 16 programming
 To use PC2-PC5 (TCK, TMS, TDI, TDO), turn off support for JTAG.

* U2 optional. Only if internal 5V power.

Title ATmega16 dual powerdrive pendel 1988			
Size A3	Number LTH Reglertechnik	Rev D	
Date 2008-02-18	Drawn by Rolf Braun		Sheet 1 of 2
File name ATmega16	ASPPK1.SCH		

Tue Jul 29, 2008